

Real natural wood



Fertigparkett

FINISH

- Remove all spacer blocs and fix the skirting boards to the walls, and finish gaps around pipes with rosettes. Once the floor has been laid it must be covered with a protective cover if further work is to be carried out in the room.
- Do not cover if under floor heating is in operation.
- If small splits/cracks have occurred during the laying these can be repaired using a putty/wax with the same colour as the floor.
- Before using a floor with an oiled surface it may be advantageous to polish the floor with f. inst. A WOCA care paste.
- Finish the gaps around the pipes with rosettes or elastic paste.
- In places where no profiles or skirting boards can be placed, the expansion gap must be filled with elastic paste.

DAILY CARE

- Daily care and maintenance of the hardwood flooring should be limited to dry cleaning, i.e. vacuuming or sweeping with a broom.
- Highly frequented areas may be wiped down with a damp cloth using a commercial pH-neutral hardwood floor cleaner, in compliance with the cleaner manufacturer's instructions.
- Never use any of the following products (or products similar in nature) on your floor: acrylic finishes, ammonia based cleaners, wax based products, detergents, bleach, polishes and oil soaps, abrasive cleaning soaps or acidic materials such as vinegar.

MAINTENANCE INSTRUCTION

Important note to keep floor & owner happy

- According to our general terms of warranty it is essential that you keep the moisture content of the air in the room all year in between 50 – 60% and a stable room temperature around 20 °C. Once it comes to heating season in the winter you may have to use an air humidifier to keep the moisture at above level.
- Once you allow moisture or temperature to be below above you might see some gaps and in worst case cracks on the surface. Wood is still a natural product with normal reaction. Normally the gaps close again in spring time. This is not a defect of the floor and not a reason to claim.
- To keep the value of your nice new flooring, it really helps to use leg protector pads under all furniture legs. Rolls under any office chairs have to be rated „W“ soft (according German DIN68131). To protect your flooring from rolls we heavily recommend polycarbonate underlay floor protection.
- Use interior and exterior doormats at entrances to collect dirt and moisture and prevent it from being tracked onto the floor.
- Area rugs are recommended in front of kitchen sinks, at all pivot points and within high-traffic areas.
- Don't allow water to stand on your floor for any length of time – wipe up immediately.
- Don't use rubber, foam back or plastic mats as they may trap moisture and possibly discolor your floor.
- Do not use vacuums with beater bars or hard heads.



Dear customer,

thank you for buying Fertigparkett hardwood flooring. To keep the value of this high end product please read following installation and maintenance instructions carefully.